









MTSP_H120_1





MTSP_H120_1N



MTSP_H120_1F5

NR	ELEMENT	MTSP_H120_1N (1/2)
1		
2		
3		
4		1
5		
6		1

NR	ELEMENT	(2/2) MTSP_H120_1N
7		1
8		2

NR


ELEMENT

1

2

3


4





1


5

6



1


NR	ELEMENT	(2/2) MTSP_H120_1F5
7		1
8		2

				MTSP_H120_1N	MTSP_H120_1F5
--	--	--	--	--------------	---------------

Nr	Element			Σ	Σ
10		DIN 9021	6x18	96	96
15		ISO 7380	M6x30	48	48
16		-	K1_d21_B	48	48
17		-	Z1_d21_B	48	48
18		DIN 985	M6	48	48
58		-	LOCTITE	1	1
61		-	KL105		6

--	--	--	--	--	--

MTSP_H120_1N
MTSP_H120_1F5





1

MTSP_H120_1N
MTSP_H120_1F5



INST_MTS_1
INST_MTS_2
INST_MTS_3
INST_MTS_5



buglo.pl/mts-manual

MANUAL